


CTF

VOLTAGE / FREQUENCY CONVERTER

DIMENSIONS



JUNCTIONS

TERMINAL	DESCRIPTION	
1	Input I+	
2	Input I-	
3	Ground	
4	Supply voltage	115 or 230Vac / 50Hz
5	Supply voltage	115 or 230Vac / 50Hz
6	Output O1-	Open Collector
7	Output O1+	Open Collector
8	N.A.	
9	Output O2-	0-24V
10	Output O2+	0-24V