

### ACCESSORIES

Supplied with the CAFD :

- extensible cord for junction with the potmicro, equipped with a 3 pins female plug at CAFD side and a 4 pins male plug A' at potmicro side
- battery charger (230Vac/50Hz to 12Vdc - 500mA), with a 2 pins female plug.

### UTILIZATION

Two modes of operation selected using the "CONTROL / MONITORING" selector:

- MONITORING position:  
controls transmitted by the potmicro are monitored thanks to FEEDER red light and CRUSTBREAKER green light.
- CONTROL position:  
enables the Crustbreaker/Feeder electro-valves to be controlled in local mode.